

Repairer Preventive Maintenance Checks and Services

6530-00-926-2151

Sterilizer, Surgical Dressing 16X36 in.

[M-Monthly, Q-Quarterly, S-Semiannually, and A-Annually]

ITEM NO	INTERVAL	ITEM TO BE INSPECTED AND PROCEDURE	IS NOT MISSION CAPABLE IF:
1	S	<p>Sterilizer</p> <p>a. Verify the components and accessories according to the Operator Preventive Maintenance Checks and Services.</p> <p>b. Inspect the unit for obvious signs of damage such as cracks, dents, leaks, or broken components.</p>	The shelves are missing.
2	S	<p>Sterilizer Operational</p> <p>a. Ensure that the unit is set up and assembled properly as directed by the Operator Preventive Maintenance Checks and Services.</p> <p>b. Ensure unit is wired per data plate diagram to conform to incoming power.</p> <p>c. Inspect door for proper operation. Ensure hinges are properly lubricated. Inspect door gasket for damage or deterioration.</p> <p>d. Inspect the case for damage. Ensure hinges and latches are properly lubricated.</p>	<p>Unit cannot be wired according to diagram.</p> <p>Sterilizer door does not close and seal.</p> <p>Damage prevents operation of the unit.</p>
3	S	<p>Sterilizer Jacket</p> <p>Verify operation of the sterilizer jacket according to the Operator Preventive Maintenance Checks and Services.</p> <p>WARNING: LIFT THE RELIEF HANDLE OF THE SAFETY VALVE OR TURN OPERATING VALVE TO THE DRY POSITION TO RELEASE ANY PRESSURE IN THE JACKET BEFORE REMOVING THE PLUG FROM THE FILLING FUNNEL. FILL THE STERILIZER JACKET WITH THE PUREST WATER AVAILABLE AND INSPECT FOR WATER LEAKS. INSPECT THE WATER LEVEL INDICATOR GAUGE AND ENSURE WATER IS AT LEAST AT ¼ MARK.</p>	<p>Jacket leaks or cannot be filled with water.</p> <p>Water level indicator gauge is broken or excessive mineral deposits obscure the reading of the water level.</p>
4	S	<p>Operation Valve</p> <p>a. Conduct operating valve checks.</p> <p>b. Verify the increase in pressure and test the safety valve by depressing the safety lever.</p>	<p>Operating valve leaks or does not operate properly.</p> <p>Pressure does not increase or if the safety valve does not release pressure when depressed.</p>